




SUPER
ZIGZAG
SEWING MACHINE
PARTS









B 101 Upper shaft arm bushing 102 Balance wheel bushing 104 Presser bar lower bushing 110 Feed bushing 111 Push button bushing 115 Presser bar upper bushing	126 Feed regulator slide block 128 Zigzag regulating knob K 101 Stop motion screw 105 Top cover set screw 106 Top cover set screw 108 Zigzag pointer knob	109 Needle bar joint pin 110 Presser bar 114 Zigzag regulating roller shaft 116 Zigzag vertical shaft 117 Lower shaft taper pin 119 Lower shaft 120 Shuttle race guide shaft 121 Shuttle race connecting rod pin 122 Shuttle race connecting rod guide pin 123 Feed rook shaft 124 Feed lifting rock shaft 128 Drop feed connecting pin 138 Zigzag adjusting link pin 140 Feed regulating shaft 143 Zigzag width regulating shaft 149 Taper pin 151 Zigzag regulating shaft 157 Feed regulating pin 159 Upper shaft
C 102 Feed cam	L 101 Crank weight 104 Needle bar connecting link 105 Zigzag link 106 Zigzag connecting link 107 Crank connecting rod 108 Oscillating rock shaft 109 Lower shaft crank 110 Shuttle race connecting rod 111 Forked rod 112 Feed rock crank	Q 101 Midle thread guide
D 101 Darnar	M 102 Needle bar thread guide 103 Thread tension release lever guide pin 104 Drop connecting rod with nut 105 Arm thread guide 107 Needle bar connecting rod	104 Presser bar lifter 105 Thread tention release lever 107 Needle plate 109 Slide plate 124 Spring connecting metal 135 Lamp cord guide 136 Lamp cord holder 139 Lower thread guide 150 Push button stopping plate 156 Spring connecting plate 159 Zigzag link plate 161 Zigzag regulating plate 162 Zigzag width graduating back plate 173 Upper thread guide 176 Drop feed assembly 177 Zigzag regulating guide 178 Zigzag regulating pointer 179 Zigzag width graduating plate settle plate
E 103 Lamp socket 104 Lamp switch 105 Gum bushing 106 Lamp cord 107 Lamp cord tube 108 Lamp bulb	N 101 Lamp cord guide set screw nut 106 Forked rod connecting hinge screw nut 108 Crank connecting rod screw nut 109 Feed bar center screw nut 110 Center screw nut 113 Zigzag pointer knob nut 201 Needle	
F 101 Shuttle race 102 Shuttle race ring 109 Bobbin case assembly 110 Bobbin 111 Shuttle body	P 102 Presser bar lifter pin 104 Taper pin 106 Stude for thread take up link 107 Thread take up crank 108 Needle bar	
G 101 Upper shaft gear		
H 102 Needle clamp 103 Feed bar 104 Needle bar connecting metal		
J 102 Zigzag slider 103 Zigzag roller 104 Lower shaft crank square roller 105 Lower shaft collar 109 Feed lifting rock shaft crank roller 110 Feed cam shaft collar 116 Reverse push button 119 Zigzag regulating shaft collar 123 Feed stitch dial knob		

181 Zigzag fix plate
 190 Lamp install plate
 191 Lamp cord holder
 199 Lamp cord guide
 203 Feed stitch regulating plate

 R 101 Zigzag cam stand
 112 Feed adjuster
 118 Zigzag width regulator
 121 Dial tension stand

 S 104 Needle bar thread guide set screw
 105 Shuttle race spring set screw
 109 Slide plate spring set screw
 115 Lower thread guide set screw
 119 Feed dog set screw
 127 Cam shaft collar set screw
 128 Zigzag length regulator set screw
 129 Lamp cord guide set screw
 132 Presser foot set screw
 133 Stop motion small screw
 135 Needle bar connecting stud set screw
 136 Bobbin winder thread guide set screw
 143 Dial tension stud set screw
 146 Zigzag regulating knob set screw
 148 Upper shaft gear set screw
 152 Zigzag cam assembly set screw
 154 Zigzag adjusting link pin lid screw
 155 Thread guide set screw
 156 Feed bushing set screw
 157 Needle plate guide screw
 158 Needle plate set screw
 161 Zigzag cam stand set screw
 168 Bobbin winder set screw
 177 Table hinge screw

181 Thread take up crank position screw
 182 Crank weight set screw
 183 Feed cam set screw
 184 Forked rod connecting hinge screw
 185 Feed regulator slide block screw
 190 Take up link set screw
 194 Upper shaft arm bushing set screw
 195 Crank connecting rod screw
 196 Feed bar center screw
 198 Center screw
 207 Zigzag regulating plate set screw
 209 Zigzag regulating pointer Guide screw
 210 Lamp cord holder set screw
 211 Zigzag frame set screw
 213 Zigzag width regulator shaft set screw
 214 Zigzag length regulator set screw
 221 Feed stitch regulating plate set screw
 223 Upper thread guide set screw
 228 Lamp cord guide set screw
 232 Arm cover strap set screw
 236 Lamp cord guide set screw

 Sp 8 Spool pin

 U 101 Stop motion clamp washer
 103 Thread cutter
 109 Slide plate spring
 110 Lever spring
 119 Feed regulating spring
 120 Feed regulating wave washer
 121 Feed regulating spring washer
 122 Push button spring
 131 Zigzag width adjusting washer

135 Zigzag width adjusting wave washer
 136 Feed stitch dial knob washer
 137 Zigzag pointer knob washer
 141 Presser bar spring

 W 11 Gum wheel
 14 Bobbin winder

 X 101 Balance weight
 103 Needle bar holder
 104 Presser bar guide
 105 Shuttle race guide
 106 Drop feed body
 129 Zigzag frame

 Z 104 Take up lever
 105 Needle bar connecting stud
 106 Presser foot
 109 Zigzag cam assembly
 112 Driver assembly
 114 Feed dog
 116 Bobbin winder thread guide
 122 Zigzag width graduating plate
 124 Pilot lens
 125 Arm cover strap
 126 Arm cover strap
 132 Zigzag mark
 133 Feed mark

